



## SOFTWARE UPDATE RELEASE NOTES

**Product:** Fusion Marine Entertainment Stereo Active Watersport Stereo

**Model:** WS-SA150B Blue  
WS-SA150R Red  
WS-SA150W White

**Version:** 1.1.2

**Language:** English 006-B2383-10 Zip File  
Dutch 006-B2383-20 Zip File  
French 006-B2383-30 Zip File  
Italian 006-B2383-40 Zip File  
German 006-B2383-50 Zip File  
Spanish 006-B2383-60 Zip File

### **Update content:**

Fixed a bug relating to Mono/stereo USB playback  
Improvement to Battery level monitoring  
General Bug fixes and improvements

## **Installation Instructions:**

To check the installed version of software go to the About Screen in the Settings Menu.

## **Install Process**

1. Download the required language zip file to your PC/Laptop.
2. Extract the Update folder to a USB flash drive
3. Connect the USB Flash Drive to the StereoActive USB Port.
4. Press and hold the I<< and >>I keys simultaneously until the "Updating" prompt is announced.
5. The Update takes about 1 minute and the "Success" prompt will be announced once the update is complete. The StereoActive will resume playback from the previous source.

## **Important Notes**

1. Ensure the USB Flash Drive is formatted to FAT32
2. Ensure the folder on the Flash Drive is named "Update"
3. Do not remove the USB Flash Drive or Press any buttons during the Update process